


When you see the camera video is red color, Purple color or other colors, please follow the guides to resolve the problem.

Like:



1. The problem is that the IR-cut still not change to normal status. Please put your hand to **cover** the lens dome cover to make the IR-cut light change. Put your hand to cover the IR-cut light for about 15-30S, to see whether the video goes to normal. When you see the video goes to normal, then it means that the IR-cut change to be normal.

2. if you still have the same problem, please click the **Reset** button to reboot the camera to have a try.